

# Installation Instructions

05-06 4.6L, Ford Mustang  
High Performance Replacement Mufflers

**46055R**



Please check Parts List below  
to insure that all parts  
are included in the product box !



Note: anti-seize should be applied to all fastener threads and pipe slip joints

## Parts List and Description

- (A) PN 46055RA - left muffler
- (B) PN 46055RB - right muffler

## Hardware List

- (2) 2-1/2" heavy-duty clamps

### **Installation instructions:**

1. Raise and support vehicle.
2. Loosen band clamps retaining stock mufflers to over-axle pipes.
3. Remove fasteners retaining muffler hangers to bottom of vehicle.
4. Remove mufflers with hangers attached from over-axle pipes and remove from vehicle.
5. Remove hangers from stock mufflers and install on Bassani mufflers in the same corresponding positions.
6. Position supplied clamps over inlets of Bassani mufflers and install mufflers onto outlets of vehicle over-axle pipes.
7. Re-attach hangers to bottom of vehicle with previously removed stock fasteners.
8. Align mufflers in desired position and tighten clamps on inlet pipe slip connectors.

**Note:** It may be necessary to loosen factory band clamps at mid point of vehicle to allow proper adjustment of mufflers. After desired adjustment is achieved, be sure to retighten clamps.

**SYSTEM HAS HIGH RESONATION!!!**

FOR TECHNICAL ASSISTANCE CALL TOLL-FREE (866) 782-3283  
2900 East La Jolla Anaheim, CA 92806