

Installation Instructions

2005-07 Ford Mustang GT / 2007 Shelby GT500 replacement mufflers

4607SR5



Please check Parts List below
to insure that all parts
are included in the product box !

(A)



(B)

Note: anti-seize
should be
applied to all
fastener threads
and pipe slip
joints

Parts List and Description

- (A) PN 4607SR5A- left muffler
(B) PN 4607SR5B- right muffler

Hardware List

- (2) 2-1/2" heavy-duty clamps
(1) anti-seize compound

Installation instructions:

- 1.) Raise and support vehicle.
- 2.) Loosen band clamps retaining stock mufflers to over-axle pipes.
- 3.) Remove fasteners retaining muffler hangers to bottom of vehicle.
- 4.) Remove mufflers with hangers attached from over-axle pipes and remove from vehicle.
- 5.) Cut or chisel muffler index lugs from outlet end of factory over-axle pipes.
- 6.) Loosen clamps attaching over-axle pipes to outlets of factory H/X pipe.
- 7.) Remove hangers from stock mufflers and install on Bassani/BX mufflers in the same corresponding positions.
- 8.) Position supplied clamps over inlets of supplied mufflers and install onto outlets of vehicle over-axle pipes.
- 9.) Re-attach hangers to bottom of vehicle with previously removed stock fasteners.
- 10.) Align mufflers for best fit and tighten clamps on mufflers.
- 11.) Equalize protrusion of tips from under rear valance by sliding mufflers/mid-pipes in or out of clamps at cross-over pipe connection as needed; tighten clamps
- 11.) Refer to included supplemental alignment instructions for additional information.

FOR TECHNICAL ASSISTANCE CALL TOLL-FREE (866) 782-3283
2900 East La Jolla Anaheim, CA 92806