

Bassani® *Xhaust*

86-93, 302, Ford Mustang
2 ½" Shorty X-pipe for Bassani Long Tube Headers
to bolt up to any 2 ½"
Muffler assembly in stock location.
Part # 5092R-2 Offroad X-pipe
Part # 5092R-3 Cat X-pipe



**Note:* 2 ½" X-pipe can only be installed with Bassani Long Tube Headers

Hardware Kit

- (4) 3/8" x 16 x 2 ½" Hex Bolts
- (4) 3/8" x 16 Flange Nuts
- (4) 3/8" Flat Washers
- (2) 6" Long Hi-Temp Hose (Blue)
- (4) #10 Size Hose Clamps
- (1) ¾" Air Tube

Installation Instructions

1. Begin by removing stock manifolds and H-pipe and installing Bassani EqualLength Long Tube Headers.
2. Slide the X-pipe into existing exhaust hanger location at rear of transmission mount.
3. Line up front ball and socket flanges and secure with supplied hardware of 3/8" x 16 x 2 ½" Hex Bolts, Washers, and Flange Nuts. **DO NOT TIGHTEN COMPLETELY.**
4. Once X-pipe is snugly secure, continue to bolt up the Cat-back Muffler system.
5. Secure rear ball and socket flanges with supplied hardware of 3/8" x 16 x 2 ½" Hex Bolts and Nuts.
6. Make final adjustments to align system and fully secure hardware.
7. Install the supplied Air Tube Extension Tube with Hi-Temp Hose and #10 Hose Clamps.
8. Lastly, start vehicle and check for exhaust leaks.