

Installation Instructions

2006-07 Dodge Charger-Magnum SRT8 / Chrysler 300C SRT8
Catalyzed mid-pipes; used to connect Bassani long-tube headers to Bassani 3" aft-cat system

616SRT3



**Please check Parts List below
to insure that all parts
are included in the product box !**



**Note: anti-seize
should be applied
to all fastener
threads, pipe slip
joints and mating
surfaces of
ball /socket
connections.**

Parts List and Description

Hardware List

(A)	PN	6163DC	-driver side converter pipe	4	-3" clamps
(B)	PN	6163PC	-passenger side converter pipe	1	-anti-seize tube
(C)	PN	6163DE	-driver side extension pipe		
(D)	PN	6163PE	-passenger side extension pipe		

Installation instructions:

- 1.) It is assumed at this point that you have already installed Bassani long-tube headers as per the instructions included within the product packaging. If you have not, do so at this time before proceeding.
- 2.) Place two supplied clamps over inlets of converter pipes and install driver and passenger side converter pipes onto header collectors.
- 3.) Place two remaining clamps over inlets of supplied extensions and install extensions onto outlets of converter pipes.
- 4.) If you are also installing a Bassani 3" aft-cat with these headers and converter pipes, as intended, discard the inlet pipes included with the aft-cat system.
- 5.) Finish installing the aft-cat system as per instructions included within product packaging.
- 6.) Install stock oxygen sensors into bungs behind catalytic converters; connect sensors to vehicle harness by using extensions included with headers.
- 7.) Reinstall body-stiffening brace under center of vehicle using stock fasteners.
- 8.) Align all system components for best fit and fully tighten all clamps and fasteners.

FOR TECHNICAL ASSISTANCE CALL TOLL-FREE (866) 782-3283
2900 East La Jolla Anaheim, CA 92806