

Installation Instructions


2008 Ford F-250/350/450, 6.4L Powerstroke diesel aft-filter system

Installs rear of the factory diesel particulate filter. Fits Crew-Cab/Long-Bed chassis.

640845 / BX640845



Please check Parts List below
to insure that all parts
are included in the product box !



Note: anti-seize
should be applied
to all fastener
threads, pipe slip
joints and mating
surfaces of
ball /socket
connections.

Parts List and Description

(A)	PN	606035A	-inlet pipe adapter
(B)	PN	640845I	-inlet pipe
(C)	PN	701120RM	-muffler
(D)	PN	640845TA	-tailpipe section A
(E)	PN	640845TB	-tailpipe section B
(F)	PN	540000	-tip

Hardware List

1	-3.5" band clamp with hole
5	-4" band clamps
1	-anti-seize tube

Installation instructions:

- 1.) Raise and support vehicle.
- 2.) Lubricate all factory rubber hangers and pipe slip-connectors with penetrating oil.
- 3.) Loosen clamp, attaching inlet of stock muffler to inlet pipe.
- 4.) Remove muffler/tailpipe assembly from inlet pipe and rubber hangers; remove from vehicle.
Removal of muffler/tailpipe can be made easier by first cutting the tailpipe from the muffler with a reciprocating saw.
- 5.) Remove hanger rod on inlet pipe from rubber frame hanger.
- 6.) Loosen clamp attaching inlet pipe to outlet of converter and remove pipe from vehicle.
- 7.) Place supplied 3.5" clamp with hole over small end of supplied adapter and install onto outlet of converter. Engage slot in adapter with index bump on converter outlet and place hole in clamp over bump. Tighten clamp fully.
- 8.) Place one supplied 4" clamp over inlet pipe slip-connector and install pipe onto adapter. Insert hanger rod on pipe into corresponding rubber hanger on frame.
- 9.) Rotate inlet pipe as needed to orient end of hanger rod, which is inserted into rubber hanger, in a horizontal position and tighten clamp at slip-connector fully.

Continued on next page...

FOR TECHNICAL ASSISTANCE CALL TOLL-FREE (866) 782-3283
2900 East La Jolla Anaheim, CA 92806

Installation instructions continued for 640845:

- 10.) Place one supplied 4" clamp over muffler inlet and install muffler onto inlet pipe.
- 11.) Place one supplied 4" clamp over inlet of tailpipe section "A" and install pipe onto muffler and into corresponding factory rubber hangers just above muffler.
- 12.) Place one supplied 4" clamp over inlet of tailpipe section "B" and install pipe into rear-most rubber frame hanger and onto outlet of tailpipe section "A".
- 13.) Place remaining 4" clamp over tip inlet and install tip onto outlet of tailpipe section "B".
- 14.) Align all components for desired fit and tighten all clamps fully.

**FOR TECHNICAL ASSISTANCE CALL TOLL-FREE (866) 782-3283
2900 East La Jolla Anaheim, CA 92806**