



Installation Instructions for FLH Slip-on Mufflers

Note: FLH Slip-on Mufflers come with the baffles pre-installed and utilizes the stock HD mounting hardware.

1. Each stock muffler is held on by a clamp at the forward end and (2) bolts at the rear underneath the saddlebags. First loosen the clamp, then remove the bolts under the bags (remove your bags for easy access to the bolts) and slide off each muffler.
2. Take your new Bassani's out of the box and slip them onto the head pipe then install the rear bolts, do not tighten completely.
3. Before you tighten completely stand the bike up and see if your new mufflers are properly aligned. After alignment is verified you may now secure all loose bolts and the clamps.
4. Wipe them clean to remove all fingerprints before starting.
5. Go ride!

"Thanks for choosing Bassani!"